

New Customer Systems - Transmitter - GPS Tracking Transmitter

After adding a System, you may add a Transmitter (Communicator) to that System.

Add System
5 - GPS Tracking Example TX

SYSTEM TXS PROGRAMMING REMINDERS

Q

TX No	Description	TX ID	Type	Prefix	Protocol	Enabled On
No Results						

ADD

CANCEL PREVIOUS NEXT

Adding a Transmitter

- Click Add
- Enter the Transmitter Details

Add System
5 - GPS Tracking Example TX

SYSTEM TXS PROGRAMMING REMINDERS

TX
TX No
4
Description
GPS Tracking Example TX
Transmitter Type
All
Receiver Line Profile
TX ID
TX Protocol
None
TX Dates
Panel Enabled
Connect Date
Termination Date
Interval
Test Unit
TX Options

Caller Id 1
Caller Id 2
Remote Address
TX Type Details

CANCEL DONE

- **Transmitter Number** - Index number (Counting number, first is 1, second is 2, etc.) **automatically generated by Manitou.**
- **Transmitter Description** - Detailed description of the Transmitter. Some example descriptions are: "Digital Dialer TXID nnnn", "TXID number", and "Accounting Reference number". Enter this based on your company's business practices.
- **Transmitter Type** - Select the one that matches the signal type or translations you utilize. DFLT allows for any intelligent format to send signals based on the Event Maps.
- **Receiver Line Prefix** - Which Receiver, Dealer, or DNIS that matches this account?
- **Transmitter ID** - This is the Panel account number. Often 4 digits on traditional alarm panels. Non-traditional or XML panels may have different number and/or letter combinations.
- When necessary, select the **Transmitter Test interval.**

All other data is optional.

Add System
5 - GPS Tracking Example TX

Receiver Line Prefix
This field is required.

TX ID
This field is required.

TX Protocol Type
None

TX Dates

Path Enabled

Connect Date

Termination Date

Interval

Test Unit

TX Options

- ☐ Generate Restore Overdues
- ☐ Any Activity Satisfies Test
- ☐ Extended Signaling
- ☐ Regular Activity Expected
- ☐ Backup TX
- ☐ Do Not Use Dealer Programming
- ☐ Raw Event Programming

TX Type Details

- ☐ Audio Capable
- ☐ Create Call Session (No Listen-In)
- ☐ Drop Listen-In if no alarm
- ☐ Video Capable
- ☐ Monitored Transmission Path
- ☐ Generate Late to Test only when Closed
- ☐ Encrypted
- ☐ Add-On Module

Notes

CANCEL DONE

Transmitter Options

The Transmitter Options allow for Transmitter specific options.

- **Generate Restore Overdue** - Ensures that any events with a Restore Required will generate a Restore Overdue if not restored within the prescribed period of time.
- **Any Activity Satisfies Test** - Allows any real signal from the panel to satisfy the test period noted in the Transmitter Test Interval.
- **Extended Signaling** - Used only on older panels where two signals are required to create one event. This must be programmed on the transmitter programming to marry together the events.
- **Regular Activity Expected** - Used only when you do not have a Transmitter Test Interval but want to be sure to verify the account signals on a regular basis.
- **Backup Transmitter** - Flags this Transmitter as a backup for billing purposes.
- **Do Not Use Dealer Programming** - skips over any Events pointed to Dealer Action patterns.
- **Raw Event Programming** - Do not choose this for any new accounts. This is enabled to allow conversion accounts to signal in their legacy fashion. This is NOT RECOMMENDED for use in Manitou.

Transmitter Type Details

Are populated from the Transmitter Type and are not editable on the Customer record.

Transmitter Notes

Optionally, you may add specifics about that transmitter including panel location or the like. This information, when entered is visible while processing alarms.

When all Transmitter information is entered as expected. Click **Done to return to the Wizard.**

When all Transmitter Details are Entered Correctly. You may repeat all additions to all Transmitters, but we recommend committing the new account to the database before doing so.
