

Tour(ID,Sequence,Timeout)

The **Tour(ID,Sequence,Timeout)** command defines which events, zones, and timeouts that define a Guard Tour at the monitored location. This is individually added to each zone involved in the guard tour. This triggers a service when created.

Text	Tour(0,1,0) ?		
Tour(0,1,0)	x	↑	↓
	ID		...
	0		
	Sequence		...
	1		
	Timeout		...
	0		

Command Parameters

- **ID** = Group number of the Tour.
 - **Sequence** = Order of zones (first, second, third, etc.). If a guard misses a zone, the alarms drop to an operator for handling.
 - **Timeout** = Period in minutes the guard has to get to the zone. Zero (0) ends the tour. If missed, the alarms drop to the operator for handling.
-