


Audio

The Audio command signifies the signal contains audio capabilities.

This requires that the Transmitter Type in use on the account's transmitter contains the "Audio Capable" option.



Command Parameters

- **Type** - Yes or Listen
 - **Yes** = Two-way audio.
 - **Listen** = Listen only without talk capability.
 - **Delay** - Time, in seconds, available to delay the alarm delivery to include the listen-in event.
-