

Unused Transmitters

The **Unused Transmitters** report returns the available transmitter IDs, or range of IDs, based on the dealer or prefix selected.

Unused Transmitters

Unused Transmitter report.

MAIN DISTRIBUTION

Title: Unused Transmitters Priority: 6

From: _____ To: _____

Transmitter ID: _____

Receiver Line Prefixes: Include Sub-Dealers

Select All | Select None

- 3xLogic
- Alarm.com
- AlarmNET
- ClearView Default Prefix

Summary View

Assigned Ranges Only

Output format: Show range counts List each open slot

Unassigned range numbering: Decimal Hex Hex, no A

Max Transmitter ID length:

PREVIOUS NEXT DISPLAY NOW DOWNLOAD (PDF) DOWNLOAD (RTF) SEND EMAIL

Report Parameters

- **Transmitter ID** - Filters the report results by the specified Transmitter ID
- **Receiver Line Prefixes** - Selects the Receiver Line Prefix, or prefixes, to include in the report results.
- **Dealer ID** - Filters the report results by the selected Dealer.
 - **Include Sub-Dealers** - If dealer selected, this allows the inclusion, or exclusion, of the Dealer's sub-dealers.
- **Summary View** - When selected, returns the results in a summary of the range.
- **Assigned Ranges Only** - When selected, returns only ranges specifically assigned.
- **Output format** - Allows the selection of how to output the results.
- **Unassigned range numbering** - Determines the numbering format.
- **Max Transmitter ID length** - Sets the whole number that seeks for the maximum Transmitter ID lengths assigned

to the ranges.
