

UL Monitoring Layout

Last Modified on 03/29/2024 12:23 pm EDT

If UL monitoring is a requirement for your operation, create a custom UL layout as follows:

1. On the **Home** page, click **Edit** then **Add Layout**.
2. Create a new layout for UL requirements, for example, *UL Tracking*.
3. Click **Select Details** for the layout. The **Select Data** card appears.
4. Select the **Health** option.
5. Select options from the **Health Specification** drop-down list and configure these options per your UL requirements.