Signal Lifetime

The **Signal Lifetime** report transmission times for signals from panel to dispatch for the period, or parameter(s) selected.

Signal Lifetime											
This report shows transmission times for signals from panel to dispatch.											
			MAIN						DISTRIBUTION		
Intie Signal Lifetime R	Phonty eport 6										
	From			То							
Date	08/30/2024	• 00:00		08/30/2024	* 23:59)					
DealerID											
Customer ID			Q 🕈			Q Ŧ					
AuthorityID											
Transmitter Type											
Receiver Line											
	- Deterile										
Include Sign	ai Detalis										
						PREVIOUS	NEXT	DISPLAY NOW	DOWNLOAD (PDF)	DOWNLOAD (RTF)	SEND EMAIL

Report Parameters

- **Date** time range to include in the report results.
- Dealer ID dealer, or dealers, to include in the report.
- Customer ID customer, or range of customers, to include in the report.
- Authority ID authority, or authorities, to include in the report results.
- Transmitter Type filters the results by the specified Transmitter Type(s).
- Receiver Line filters the results by the specified Receiver Line(s).

• Include Signal Details - includes the detail of the events included within the report.